

SKIN REPLENISHING SERUM

MK 3/10-7

| PHASE | INGREDIENTS | % W/W |
|-------|--|-------|
| A | TEGO® Care 165 (Glyceryl Stearate; PEG-100 Stearate) | 3.00 |
| | TEGOSOFT® APM (PPG-3 Myristyl Ether) | 3.00 |
| | Stearyl Alcohol | 0.50 |
| | Isononyl Isononanoate | 4.00 |
| | Hydrogenated Polyisobutene | 3.00 |
| | Tocopherol | 0.50 |
| B | Water | 77.75 |
| | Butylene Glycol | 5.00 |
| | SKINMIMICS® (Ceteareth-25; Glycerin; Cetyl Alcohol; Behenic Acid; Cholesterol; Ceramide EOP; Ceramide EOS; Ceramide NP; Ceramide NS; Ceramide AP; Caprooyl Phytospingosine; Caprooyl Sphingosine) | 2.50 |
| C | Sepigel 305 (Polyacrylamide (and) C13-14 Isoparaffin (and) Laureth-7) | 0.75 |
| Z | Preservative, Perfume | q.s. |

Processing

1. Heat phase A and B separately to approx. 70 - 75 °C. 2. Add phase A to phase B with stirring. 3. Homogenise. 4. Cool with gentle stirring. 5. Add phase C below 40 °C. 1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Viscosity 11 Pas (Brookfield RV DV-I, sp. 4, 10 rpm)

pH Value 6.2-6.8

Stability Proven

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH

Goldschmidtstr. 100
45127 Essen
Germany

Phone +49 201 173 2436
personal-care@evonik.com
www.evonik.com/personal-care