

FACE & BODY CREAM

F 11/10-5

PHASE	INGREDIENTS	% W/W
A	TEGO® Care PSC 3 MB (Polyglyceryl-3 Dicitrate/Stearate)	3.00
	TEGIN® M Pellets MB (Glyceryl Stearate)	1.20
	Stearyl Alcohol	1.30
	CERAMIDE III (Ceramide NP)	0.10
	TEGOSOFT® OER MB (Oleyl Erucate)	5.00
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	8.50
	Persea Gratissima (Avocado) Oil	6.00
B	Water	66.90
	Glycerin	3.00
C	Water	3.80
	Keltrol CG-SFT (Xanthan Gum)	0.20
D	Sodium Hydroxide (10 % in water)	0.20
E	Rokonsal BSB-N (Benzyl Alcohol; Glycerin; Benzoic Acid; Sorbic Acid)	0.80
Z	Perfume	q.s.

Processing

1. Heat phase A and B separately to appr. 90°C. 2. Add phase A to phase B with stirring¹⁾. 3. Homogenise. 4. Cool with gentle stirring and add phase C below 40°C 5. Add phase D. 6. Add phase E and adjust the pH to 5.0 - 5.5 1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**