

HYACARE LIP FILLER

AS 1897-3

Caring lip Balm with HyaCare Filler CL, who instantly fills fine wrinkles of the lip and thoroughly hydrates the skin.

PHASE	INGREDIENTS	% W/W
A	Octyldodecanol	15.0
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	10.0
	TEGOSOFT® OER MB (Oleyl Erucate)	2.0
	TEGOSOFT® MM MB (Myristyl Myristate)	5.0
	Ricinus Communis (Castor) Seed Oil	32.2
	Cremerlin PURA (Olus (Vegetable) Oil)	10.0
	BW Ester BW 67 (Stearyl Beeswax; Behenyl Beeswax)	6.5
	Kahlwax 1899 (Ozokerite)	6.0
	Kahlwax 8104 (Cera Alba)	5.0
	Kahlwax 2039L (Euphorbia Cerifera (Candellila) Wax)	3.0
B	Tocopherol	0.1
	Perfume	0.2
C	HyaCare® Filler CL (Aqua; Ethylhexyl Stearate; Sodium Hyaluronate Crosspolymer; Polyglyceryl-4 Diisostearate/Polyhydroxystearate/Sebacate; Sodium Isostearate)	5.0

Processing

1. Heat phase A to approx. 80 -85 °C until the waxes are completely melted.
2. Cool down to 64 °C while stirring.
3. Add phase B and C and mix shortly.
4. Mould the mixture at 60-62 °C.
5. Cool down the mould to -15 °C and stay for 15-35 min.
6. Demould and pack.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**