

AGE CORRECTING HYDRO LOTION

MAC 831/9

Cold processable Body Lotion. It helps to sooth the skin and increase moisturization.

PHASE	INGREDIENTS	% W/W
A	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	2.00
	TEGOSOFT® CI (Cetearyl Isononanoate)	8.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate)	5.50
	Persea Gratissima (Avocado) Oil	2.00
	TEGO® Carbomer 341 ER (Acrylates/C10-30 Alkyl Acrylate Crosspolymer)	0.45
B	TEGO® Natural Betaine (Betaine)	5.00
	Water	69.55
	TEGO® Stemlastin (Cyanidium Caldarium Extract)	2.50
	TEGO® SMO 80 V (Polysorbate 80)	1.00
	Glycerin	3.00
C	Sodium Hydroxide (10 % in water)	q.s.
D	Euxyl PE 9010 (Phenoxyethanol,Ethylhexylglycerin)	1.00
Z	Perfume	q.s.

Processing

1. Prepare phase A and B separately at room temperature.
2. Combine phases A and B without stirring.
3. Homogenize.
4. Add phases C and D and stir well.

Remarks

Viscosity: 32 Pas (Brookfield RV DV-I, sp. 5, 5 rpm)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**