



Formulation

ADVANCED SHEEN HAIR PROTECTING TREATMENT

EA 120315-HM

INGREDIENTS

PHASE	INGREDIENTS	% W/W
A	Water	58.80
	Glycerin	3.00
	ABIL® Quat 3272 (Quaternium-80)	0.50
	TEGO® Cosmo C 100 (Creatine)	0.50
B	TEGO® Alkanol 1618 (Cetearyl Alcohol)	7.00
	Petrolatum	4.00
	Mineral Oil	10.00
	TEGO® SMS 60 (Polysorbate 60)	1.20
	TEGO® Care LTP MB (Sorbitan Laurate; Polyglyceryl-4 Laurate; Dilauryl Citrate)	2.00
	TEGOSOFT PIB 5 basic (Polybutene)	10.00
	VARISOFT® EQ 100 (Bis-(Isostearoyl/Oleoyl Isopropyl) Dimonium Methosulfate)	1.00
	TEGOSOFT® XC (Phenoxyethyl Caprylate)	0.50
C	Euxyl K 900 (Benzyl Alcohol, Ethylhexylglycerin, Tocopherol)	1.00
D	Perfume "Azura 231517"	0.50

PROCESSING

1. Charge vessel with water from phase A and heat to 75°C.
2. Add remaining ingredients of phase A and stir until uniform.
3. Mix ingredients of phase B and heat to 75°C.
4. Slowly add phase B to A.
5. Homogenize.
6. Cool down to 40°C.
7. Add phase C and D with stirring.

REMARKS

Viscosity: 72.000 mPas (Brookfield RV DV-I, sp. C, 12 rpm)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care