

# POWER MOISTURIZING LOTION

MAC 836/2

O/W Body Lotion with excellent moisturizing properties

PHASE	INGREDIENTS	% W/W
A	TEGO® Care PBS 6 MB (Polyglyceryl-6 Stearate (and) Polyglyceryl-6 Behenate)	3.00
	TEGO® Alkanol 1618 (Cetearyl Alcohol)	0.75
	TEGIN® M Pellets MB (Glyceryl Stearate)	0.75
	TEGOSOFT® M (Isopropyl Myristate )	6.00
	TEGOSOFT® OS (Ethylhexyl Stearate )	6.00
	TEGOSOFT® OER MB (Oleyl Erucate)	3.50
	B	Water
C	Keltrol CG-SFT (Xanthan Gum)	0.50
	Glycerin	3.00
	Water	10.00
D	LACTIL® (Sodium Lactate; Sodium PCA; Glycine; Fructose; Urea; Niacinamide; Inositol; Sodium Benzoate; Lactic Acid )	5.00
Z	Preservative, Perfume	q.s.

## Processing

1. Heat phase A and B separately to 70 - 75 °C.
  2. Add phase A to phase B with stirring<sup>1)</sup>.
  3. Homogenise.
  4. Cool with gentle stirring.
  5. Add phase C at 40 °C.
  6. Homogenise for a short time.
  7. Add phase D
- 1) Important: If phase A has to be charged into the vessel first, phase B must be added **without stirring**.

**Disclaimer:**

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

**Evonik Nutrition & Care GmbH**

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

**personal-care@evonik.com****[www.evonik.com/personal-care](http://www.evonik.com/personal-care)**