

INTENSE MOISTURIZING REPAIR AND TONER

CHN 009-17

PHASE	INGREDIENTS	% W/W
A	SKINMIMICS® (Ceteareth-25; Glycerin; Cetyl Alcohol; Behenic Acid; Cholesterol; Ceramide EOP; Ceramide EOS; Ceramide NP; Ceramide NS; Ceramide AP; Caprooyl Phytospingosine; Caprooyl Sphingosine)	1.00
	HyaCare® (Sodium Hyaluronate)	0.05
	Water	77.45
	Ethanol	2.50
B	TEGO® Carbomer 341 ER (Acrylates/C10-30 Alkyl Acrylate Crosspolymer)	0.05
	Water	9.95
C	Sodium Hydroxide (10 % in water)	q.s.
D	TEGO® Natural Betaine (Betaine)	1.50
	Glycerin	3.00
	Propylene Glycol	1.00
	Butylene Glycol	1.00
	Glycereth-8 Macadamia Seed Oil Esters	1.00
	TEGOSOFT® GMC 6 (PEG-6 Caprylic/Capric Glycerides)	1.50
Z	Preservative, Perfume	q.s.

Processing

1. Mix Phase A homogeneously.
2. Add Phase B with stirring.
- 3 Adjust pH with Phase C to appr. 6-6.5.
4. Add the ingredients of Phase D step by step.
5. Add perfume and preservative.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**