

WATER DROP FOUNDATION

SF 8/15-5

PHASE	INGREDIENTS	% W/W
A	ABIL® EM 180 (Cetyl PEG/PPG-10/1 Dimethicone)	1.20
	ABIL® Wax 9801 (Cetyl Dimethicone)	2.00
	Cyclopentasiloxane	5.00
	AEROSIL R 972 V (Silica Dimethylsilylate)	0.40
B	TEGOSOFT® AC MB (Isoamyl Cocoate)	5.00
	Unipure Yellow LC 182 AS-EM (CI 77492, Iron Oxides, Triethoxycaprylylsilane)	0.45
	Unipure Red LC 381 AS-EM (CI 77491, Iron Oxides, Triethoxycaprylylsilane)	0.06
	Unipure Black LC 989 AS-EM (CI 77499, Iron Oxides, Triethoxycaprylylsilane)	0.04
	BTD-11S2 (Titanium Dioxide; Triethoxycaprylylsilane)	3.19
C	Water	65.76
	Propylene Glycol	15.00
	Magnesium Sulfate Heptahydrate	1.20
D	EUXYL PE 9010 (Phenoxyethanol; Ethylhexylglycerin)	0.70
Z	Perfume	q.s.

Processing

1. Disperse pigments in phase B until uniform.
2. Add phase A into phase B and stir well.
3. Add phase C into A/B slowly while stirring at approx. 500 rpm.
4. Homogenize for 2 minutes at 1300 rpm.
5. Add phase D and Z. Stir well.

Remarks

Emulsion viscosity: 15 Pas (Brookfield RV DV-I, sp. 6, 50 rpm)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**