

# TATTOO PREPARATORY LOTION

DCA-5827-58

Strengthen your skin before tattooing. Before having skin tattooed, it is recommended to prepare it applying a moisturizing lotion. This lotion combines three ingredients: SKINMIMICS, SPHINGOKINE NP and TEGOSOFT DEC

PHASE	INGREDIENTS	% W/W
A	AXOL® C 62 Pellets MB (Glyceryl Stearate Citrate )	1.50
	TEGIN® M Pellets MB (Glyceryl Stearate)	1.00
	TEGO® Alkanol 1618 (Cetearyl Alcohol)	0.75
	TEGOSOFT® TN (C12-15 Alkyl Benzoate )	5.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate )	4.20
	SPHINGOKINE® NP (Caprooyl Phytosphingosine)	0.20
	Tocopheryl Acetate	1.00
	Pentylene Glycol	5.00
	B	Glycerin
Water		64.60
C	Mineral Oil	0.80
	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0.25
D	TEGO® Stemlastin (Cyanidium Caldarium Extract)	5.00
	SKINMIMICS® (Ceteareth-25; Glycerin; Cetyl Alcohol; Behenic Acid; Cholesterol; Ceramide EOP; Ceramide EOS; Ceramide NP; Ceramide NS; Ceramide AP; Caprooyl Phytosphingosine; Caprooyl Sphingosine )	5.00
E	Sodium Hydroxide (10 % in water)	q.s.
F	Euxyl K 900 (Benzyl Alcohol, Ethylhexylglycerin, Tocopherol)	0.70

## Processing

1. Prepare phases A and B heating to 85 °C separately.

2. Add phase B to A without stirring.
3. Homogenize.
4. Cool down to 60 °C with simple stirring.
5. Add phase C and homogenize for a short time.
6. Cool while stirring to approx. 40 °C and add phase D.
7. Adjust pH with phase E to 5.5-6.5.
8. Stir well and add phase F. Stir again.

## Remarks

Viscosity: 18 Pas (Brookfield RV DV-I, sp. 4, 5 rpm)

### Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

### Evonik Nutrition & Care GmbH

Goldschmidtstraße 100  
45127 Essen, Germany  
P.O. BOX 45116 Essen  
Phone +49 0201 173 2546  
Fax +49 0201 173 712546  
[personal-care@evonik.com](mailto:personal-care@evonik.com)  
[www.evonik.com/personal-care](http://www.evonik.com/personal-care)