

NATURAL O/W HAND CREAM

MMS 5834-009

PHASE	INGREDIENTS	% W/W
A	TEGO® Care PSC 3 MB (Polyglyceryl-3 Dicitrate/Stearate)	2.50
	TEGOSOFT® AC MB (Isoamyl Cocoate)	7.00
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	5.50
	Prunus Amygdalus Dulcis (Sweet Almond) Oil	5.00
B	Glycerin	3.00
	Water	75.80
C	Sodium Hydroxide (10 % in water)	q.s.
D	Xanthan Gum	0.50
E	Euxyl K 900 (Benzyl Alcohol, Ethylhexylglycerin, Tocopherol)	0.70
Z	Perfume	q.s.

Processing

1. Heat phase A and B separately to approx. 70 - 75°C.
2. Add phase A to phase B with stirring. 1)
3. Homogenize.
4. Cool with gentle stirring and add phase C at 40°C.
5. Homogenize for a short time.
6. Add phase D and E and stir well.
7. Adjust the pH to 5.0 - 5.5

1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Remarks

Viscosity: 73 Pas (Brookfield, Sp. 93, 10 rpm)
pH: ~5.5

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**