



## Formulation

# O/W REVITALIZING SOFT CREAM

JS 8/16-15

## INGREDIENTS

PHASE	INGREDIENTS	% W/W
A	TEGO® Care LTP MB (Sorbitan Laurate; Polyglyceryl-4 Laurate; Dilauryl Citrate )	2.0
	TEGIN® M Pellets MB (Glyceryl Stearate)	3.5
	Stearyl Alcohol	3.0
	TEGOSOFT® P (Isopropyl Palmitate )	6.0
	Mineral Oil	5.5
B	TEGO® Cosmo C 100 (Creatine)	0.5
	Glycerin	3.0
	Water	75.3
C	TEGO® Carbomer 134 (Carbomer)	0.1
	TEGOSOFT® P (Isopropyl Palmitate )	0.4
D	Sodium Hydroxide (10 % in water)	q.s.
E	Euxyl PE 9010 (Phenoxyethanol, Ethylhexylglycerin)	0.7
Z	Perfume	q.s.

## PROCESSING

1. Heat phase A and B separately to approx. 80 °C.
2. Add phase A to phase B with stirring. 1)

3. Homogenize.
4. Cool with gentle stirring to approx. 60 °C and add phase C.
5. Homogenize for a short time.
6. Cool with gentle stirring and add phase D and E below 40 °C.

1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

## REMARKS

Viscosity (Brookfield RV DV-I, sp. 93, 10 rpm): 32 Pa\*s

### Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

### Evonik Nutrition & Care GmbH

Goldschmidtstraße 100  
45127 Essen, Germany  
P.O. BOX 45116 Essen  
Phone +49 0201 173 2546  
Fax +49 0201 173 712546  
[personal-care@evonik.com](mailto:personal-care@evonik.com)  
[www.evonik.com/personal-care](http://www.evonik.com/personal-care)