

SILKY BODY LOTION

JS 8/16-4

Moisturizing W/O Lotion that improves the barrier function of the Skin and provides the Skin with NMF substances.

| PHASE | INGREDIENTS | % W/W |
|-------|--|-------|
| A | TEGOSOFT® OS (Ethylhexyl Stearate) | 5.00 |
| | ABIL® EM 90 (Cetyl PEG/PPG-10/1 Dimethicone) | 2.50 |
| | Hydrogenated Castor Oil | 0.50 |
| | Paraffin (and) Microcrystalline Wax (Microcrystalline Wax) | 0.50 |
| | TEGOSOFT® CT (Caprylic/Capric Triglyceride) | 10.00 |
| | TEGOSOFT® DEC (Diethylhexyl Carbonate) | 5.00 |
| | TEGOSOFT® TN (C12-15 Alkyl Benzoate) | 5.00 |
| B | Water | 63.30 |
| | Glycerin | 3.00 |
| | LACTIL® (Sodium Lactate; Sodium PCA; Glycine; Fructose; Urea; Niacinamide; Inositol; Sodium Benzoate; Lactic Acid) | 2.00 |
| | SK-INFLUX® V MB (Ceramide NP; Ceramide AP; Ceramide EOP; Phytosphingosine; Cholesterol; Sodium Lauroyl Lactylate; Carbomer; Xanthan Gum) | 2.00 |
| | Sodium Chloride | 0.50 |
| C | Euxyl K 900 (Benzyl Alcohol, Ethylhexylglycerin, Tocopherol) | 0.70 |
| Z | Perfume | q.s. |

Processing

1. Heat phase A to approx. 80 °C.
2. Add phase B (80 °C or room temperature) slowly while stirring.
3. Homogenize for a short time.
4. Cool with gentle stirring below 30 °C, add phase C and homogenize again.

Remarks

Viscosity: 8 Pas (Brookfield RV DV-I, sp. 5, 10 rpm)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care