

TRIPLE POWER HYALURON CREAM

MAC 889/1

An O/W anti-wrinkle cream based on a hyaluron complex with three different types of hyaluronic acid: HyaCare®, a skin identical anti-aging moisturizer, HyaCare 50, the tight junction strengthening hyaluronic acid and HyaCare® Filler CL, the topical wrinkle smoother.

PHASE	INGREDIENTS	% W/W
A	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	1.0
	TEGO® Care 450 MB (Polyglyceryl-3 Methylglucose Distearate)	2.0
	TEGIN® M Pellets MB (Glyceryl Stearate)	3.5
	Stearyl Alcohol	2.0
	TEGOSOFT® OS (Ethylhexyl Stearate)	7.5
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	7.5
B	Water	70.3
	HyaCare® (Sodium Hyaluronate)	0.1
	HyaCare® 50 (Hydrolyzed Hyaluronic Acid)	0.1
	Glycerin	3.0
C	TEGO® Carbomer 134 (Carbomer)	0.2
	TEGOSOFT® OS (Ethylhexyl Stearate)	0.8
D	HyaCare® Filler CL (Aqua; Ethylhexyl Stearate; Sodium Hyaluronate Crosspolymer; Polyglyceryl-4 Diisostearate/Polyhydroxystearate/Sebacate; Sodium Isostearate)	2.0
E	Sodium Hydroxide (10 % in water)	q.s.
Z	Preservative, Perfume	q.s.

Processing

1. Heat phase A and B separately to approx. 70-75 °C. 2. Add phase A to phase B with stirring. 3. Homogenise. 4. Cool with gentle stirring. 5. Add phase C at 60 °C and homogenize again. 6. Add phase D at 60 °C and stir well. 7. Add phase E below 40 °C. 1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**