

ANTI-GRAVITY FACE CARE MOUSSE

FU 07/18-1

Face Care Mousse with strong anti-aging properties.

PHASE	INGREDIENTS	% W/W
A	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	2.50
	Dimethicone (5 mPas)	5.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate)	4.00
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	3.00
	TEGOSOFT® CR MB (Cetyl Ricinoleate)	1.00
B	TEGO® Pep UP (Tetrapeptide-4; Glycerin)	4.00
	SK-INFLUX® V MB (Ceramide NP; Ceramide AP; Ceramide EOP; Phytosphingosine; Cholesterol; Sodium Lauroyl Lactylate; Carbomer; Xanthan Gum)	1.00
	TEGO® Cosmo C 100 (Creatine)	0.50
	Panthenol	0.50
	Allantoin	0.20
C	Water	73.60
	Carbomer	0.30
	TEGOSOFT® OS (Ethylhexyl Stearate)	1.60
	Keltrol CG-SFT (Xanthan Gum)	0.10
D	Sodium Hydroxide (10 % in water)	q.s.
E	TEGO® Betain 810 (Capryl/Capramidopropyl Betaine)	1.00
	REWOTERIC® AM C (Sodium Cocoamphoacetate)	1.00
	Euxyl PE 9010 (Phenoxyethanol, Ethylhexylglycerin)	0.70
Z	Perfume	q.s.

Processing

1. Heat phase A up to 40° C.
2. Add phase A to phase B with stirring¹).
3. Homogenize.
4. Add phase C and homogenize for a short time.
5. Add phase D and stir well.
6. Add phase E and stir well.

1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Remarks

Mix with Propellant (Butane/Propane/Isobutane)
Ratio: 90% Emulsion, 10% Propellant

Formulation viscosity: 5 Pas (Brookfield RVT, spindle 4, 5 rpm)

Formulation pH= 6.4.

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care