

CONTOURING TRANSFORMATION GEL

MKM-6057-006

Redefine yourself... with a light, silky-feeling gel that promotes the appearance of firmer skin while melting into the skin for a more even appearance

PHASE	INGREDIENTS	% W/W
A	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	2.00
	ABIL® Wax 9840 (Cetyl Dimethicone)	2.00
	TEGO® Xymenynic (Caprylic/Capric Triglyceride; Xymenynic Acid)	2.50
	TEGO® Carbomer 140 (Carbomer)	0.20
	Cyclopentasiloxane	2.00
B	Glycerin	3.00
	Water	86.40
	Ethanol	1.50
C	Sodium Hydroxide (10 % in water)	0.40
Z	Preservative, Perfume	q.s.

Processing

1. Add phase A to phase B with stirring1).
 2. Homogenize.
 3. Add phase C and Z and homogenize for a short time.
- 1)Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Remarks

Viscosity: 10 - 15 Pas (Brookfield DV-II+Pro, sp. 4, 5 rpm)

pH: 6.0 - 7.0

Antimicrobial effectiveness testing: not performed

* Formulation was tested on emulsion stability with 0.70% Phenoxyethanol; Ethylhexylglycerin (Euxyl PE 9010, Schülke & Mayr GmbH)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com**www.evonik.com/personal-care**