

HYDRATING ROSÉ DAY CREAM

FU 01/18-17

A non-greasy formula which hydrate and protect the skin leaving face looking rosy and fresh.

PHASE	INGREDIENTS	% W/W
A	dermofeel® NC MB (Polyglyceryl-3 Distearate; Glyceryl Stearate Citrate)	4.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate)	7.00
	Cera Alba	2.00
B	Water	55.29
	Propylene Glycol	11.00
	Glycerin	4.00
	HyaCare® 50 (Hydrolyzed Hyaluronic Acid)	0.20
	Submica E (Mica)	5.00
	D&C Red 21 ALUM LAKE MS (CI 45380, Red 21 Lake)	0.01
C	Keltrol CG-SFT (Xanthan Gum)	0.50
D	Alcohol	10.00
E	dermosoft® PEA (Phenethyl Alcohol)	1.00

Processing

1. Heat phase A and B separately to 70 - 75 °C.
2. Add phase A to phase B with stirring¹⁾.
3. Homogenise.
4. Cool with gentle stirring.
5. Add phase C at 40 °C.
6. Homogenise for a short time.
7. Add phase D and E below 30 °C and stir well.
8. Adjust pH value to 7.0.

1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Remarks

Viscosity: 55 Pa*s (Brookfield DV-I, Sp. 93 / 10 rpm)

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care