

# EASY SPREAD AND CARE LOTION

JS 12/17-8

PHASE	INGREDIENTS	% W/W
A	ISOLAN® GPS (Polyglyceryl-4 Diisostearate/Polyhydroxystearate/ Sebacate)	3.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate )	10.00
	TEGOSOFT® OP (Ethylhexyl Palmitate )	9.00
	dermosoft® Octiol (Caprylyl Glycol)	0.30
	Zinc Stearate	0.50
B	Water	73.20
	Glycerin	3.00
	Zinc Sulfate Heptahydrate	1.00

## Processing

1. Disperse Zinc Stearate in phase A using Ultra-Turrax.
2. Prepare phase B separately at room temperature.
3. Add phase B at room temperature slowly to phase A while stirring.
4. Homogenize.

## Remarks

Emulsion viscosity: 12 Pa\*s  
(Brookfield RV DV-I, sp. 93, 10 rpm)

Microbiological safety: challenge test passed

**Viscosity** 12 Pa\*s (Brookfield RV DV-I, sp. 93, 10 rpm)

**Stability** Proven

**Microbiological Safety** Challenge test passed

**Disclaimer:**

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

**Evonik Nutrition & Care GmbH**

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

**personal-care@evonik.com****[www.evonik.com/personal-care](http://www.evonik.com/personal-care)**