

AGE DEFENSE SLEEPING FACIAL MASK

SAC-6056-169A

Age Defense Sleeping Facial Mask makes the best out of a long contact time during your beauty sleep. Offering hydration and anti-aging effects, together with energizing and protection/prevention/regeneration actions in one product, with no extra steps to your day to day beauty routine.

PHASE	INGREDIENTS	% W/W
A	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	0.50
	ABIL® 350 (Dimethicone)	1.50
	TEGOSOFT® OS (Ethylhexyl Stearate)	4.00
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	4.00
B	TEGO® Carbomer 341 ER (Acrylates/C10-30 Alkyl Acrylate Crosspolymer)	0.60
	HyaCare® (Sodium Hyaluronate)	0.10
	HyaCare® 50 (Hydrolyzed Hyaluronic Acid)	0.10
	SKINMIMICS® (Ceteareth-25; Glycerin; Cetyl Alcohol; Behenic Acid; Cholesterol; Ceramide EOP; Ceramide EOS; Ceramide NP; Ceramide NS; Ceramide AP; Caprooyl Phytosphingosine; Caprooyl Sphingosine)	2.50
	Glycerin	5.00
	Water	78.70
C	ROVISOME® Q10 NG (Water (USA)/Aqua (EU); Glycerin; Lecithin; Ubiquinone)	2.00
D	Verstatil® PC (Phenoxyethanol; Caprylyl Glycol)	1.00
E	Sodium Hydroxide (10 % in water)	q.s.

Processing

1. Disperse the carbomer in water.
2. Add the other ingredients of phase B.
3. Prepare phase A separately.
4. Add phase A to phase B with stirring.
5. Homogenize.
6. Add phase C and mix well.
7. Add phase D and mix well.

8. Adjust pH to 5.5 using phase E.

Remarks

Viscosity: 49450 cPs (Brookfield DV-II+ Pro, Helipath, sp. 93, 10 rpm)

pH: 5.0 - 5.5

Appearance Lotion

Viscosity 49450 CPs

pH Value 5.0 - 5.5

Stability Proven

Microbiological Safety Challenge test passed

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care