

QUICKLY ABSORBING SILKY BODY SPRAY

H 31/18-12

symbio®prot V MB provides a silky & light skin feel similar to silicone O/W emulsifiers. Fast absorption during application. Compatible with all kinds of cosmetic oils.

PHASE	INGREDIENTS	% W/W
A	symbio®prot V MB (Hydrolyzed Vegetable Protein; Sodium Citrate; Magnesium Stearate; Xanthan Gum)	2.00
	TEGOSOFT® DEC (Diethylhexyl Carbonate)	7.00
	dermofeel® sensolv MB (Isoamyl Laurate)	6.00
	TEGOSOFT® P (Isopropyl Palmitate)	4.70
	Verstatil® BOB (Benzyl Alcohol; Caprylyl Glycol; Benzoic Acid)	1.30
B	Glycerin	3.00
	Water	76.0
Z	Perfume	q.s.

Processing

1. Heat phase A and B separately to approx. 75 °C.
 2. Add phase A to phase B with stirring¹⁾.
 3. Homogenize.
 4. Cool with gentle stirring to below 30 °C.
- 1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Remarks

Natural content cn (incl. water, ISO 16128): 76,4 %
Natural origin content cno (incl. water, ISO 16128): 91 %

Viscosity 5.5 Pas (Brookfield RV DV-I, sp 4, 5 rpm)

pH Value 6.8 - 7.0

Stability Proven

Microbiological Safety Challenge test passed

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Operations GmbH

Goldschmidtstr. 100
45127 Essen
Germany

Phone +49 201 173 2436
personal-care@evonik.com
www.evonik.com/personal-care