

ANTI-DARK CIRCLE EYE CREAM

ESG 1027/YT-01

PHASE	INGREDIENTS	% W/W
A	TEGO® Care 450 MB (Polyglyceryl-3 Methylglucose Distearate)	3.00
	TEGIN® M Pellets MB (Glyceryl Stearate)	2.00
	TEGO® Alkanol 1618 (Cetearyl Alcohol)	2.00
	TEGOSOFT® DC MB (Decyl Cocoate)	9.50
	TEGOSOFT® CT (Caprylic/Capric Triglyceride)	7.50
	Avocado Oil	2.00
	Tocopheryl Acetate	0.50
B	Water	64.30
	Glycerin	3.00
	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0.20
C	Lactic Acid (10 % in water)	q.s.
D	ROVISOME® F.E.C. (Water (USA)/Aqua (EU); Alcohol; Lecithin; Escin; Ascophyllum Nodosum Extract; Caffeine; Potassium Phosphate)	5.00
E	Verstatil® PC (Phenoxyethanol; Caprylyl Glycol)	1.00

Processing

1. Heat phase A and B separately to approx. 75 °C.
2. Add phase A to phase B with stirring¹⁾.
3. Homogenize.
4. Cool with gentle stirring to approx. 40 °C and add phase C. Adjust the pH to 5.5 - 6.0 and stir until uniform.
5. Add phase D and E and stir well.

1) Important: If phase A has to be charged into the vessel first, phase B must be added **without stirring**.

Viscosity 5,000 - 10,000cP (Brookfield DV2T Extra, sp. Helipath-C, 30 rpm)

pH Value 5.5 - 6.0

Stability Proven

Microbiological Safety Challenge test passed

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100

45127 Essen, Germany

P.O. BOX 45116 Essen

Phone +49 0201 173 2546

Fax +49 0201 173 712546

personal-care@evonik.com

www.evonik.com/personal-care