

CALENDULA REPAIR & MOISTURE CREAM

CNA 036-010

O/W cream addressing sensitive skin. It soothes the skin and provides additional moisturization.

PHASE	INGREDIENTS	% W/W
A	TEGO® Care 450 MB (Polyglyceryl-3 Methylglucose Distearate)	1.50
	ABIL® Care XL 80 MB (Bis-PEG/PPG-20/5 PEG/PPG-20/5 Dimethicone; Methoxy PEG/PPG-25/4 Dimethicone; Caprylic/Capric Triglyceride)	0.50
	Stearyl Alcohol	1.50
	TEGIN® M Pellets MB (Glyceryl Stearate)	2.50
	TEGOSOFT® M (Isopropyl Myristate)	6.50
	TEGOSOFT® APM (PPG-3 Myristyl Ether)	4.80
	TEGOSOFT® MM MB (Myristyl Myristate)	0.50
	Phytosphingosine SLC (Salicyloyl Phytosphingosine)	0.10
B	TEGO® Natural Betaine (Betaine)	1.00
	Glycerin	3.00
	Water	70.00
C	Carbomer	0.20
	Xanthan Gum	0.10
	TEGOSOFT® M (Isopropyl Myristate)	0.80
D	SK-INFLUX® V MB (Ceramide NP; Ceramide AP; Ceramide EOP; Phytosphingosine; Cholesterol; Sodium Lauroyl Lactylate; Carbomer; Xanthan Gum; Phenoxyethanol; Ethylhexylglycerin; Water/Aqua)	2.00
	ROVISOME® HA NG (Water (USA)/Aqua (EU); Glycerin; Lecithin; Sodium Hyaluronate)	2.00
	ROVISOME® Sensitive NG (Water/Aqua; Glycerin; Lecithin; Dipotassium Glycyrrhizate; Calendula Officinalis Extract; Lonicera Caprifolium Flower Extract; Lonicera Japonica Flower Extract; Benzyl Alcohol; Benzoic Acid; Dehydroacetic Acid)	2.00

Sodium Hydroxide (10 % in water)	q.s.
Verstatil® PC (Phenoxyethanol; Caprylyl Glycol)	1.00
Perfume	q.s.

Processing

1. Heat phase A and B separately to approx. 80 °C.
 2. Add phase A to phase B with stirring¹⁾.
 3. Homogenise.
 4. Cool with gentle stirring to approx. 60 °C and add phase C. Homogenise for a short time.
 5. Cool with gentle stirring and add the ingredients of phase D. Adjust pH to 6.0-6.5.
- 1) Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

Appearance Cream

pH Value 6.0-6.5

Stability Proven

Disclaimer:

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third-party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments. The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.

Evonik Nutrition & Care GmbH

Goldschmidtstraße 100
45127 Essen, Germany
P.O. BOX 45116 Essen
Phone +49 0201 173 2546
Fax +49 0201 173 712546
personal-care@evonik.com
www.evonik.com/personal-care